


WebRelay-10™

Users Manual



Revision: 1.01 – November 10, 2008

Covers: X-WR-10R12-I



a division of...
Xytronix Research & Design, Inc.
North Logan, Utah, USA

Contents

Trademark and Copyright Information

Warranty

FCC Statement

Installation Guidelines (Read Before Installing)

Section 1: Introduction

1.1 Features

1.2 WebRelay-10™ Models Available

1.3 Connectors & Indicators

Section 2: Installation and Setup

2.1 Mounting

2.2 Connection

2.2.1 Power Supply Connection

2.2.2 Network Connection

2.2.3 Relay Connection

2.3 Establishing Communications for Setup

2.3.1 Option 1: Assign a temporary IP address to WebRelay-10™

2.3.2 Option 2: Assign a temporary IP address to configuration computer

2.3.3 Open Configuration Web Page

2.4 Web-Based Setup

2.4.1 Main Setup Page

2.4.2 Network Setup Page

2.4.3 Password Setup Page

2.4.4 Control Page Setup Page

2.4.5 Relay Options Page

Section 3: Operation

3.1 Browser Operation

3.2 XML Operation

3.3 Modbus Operation

3.3.1 Read Coils (Modbus Function Code 01 (0x01))

3.3.2 Write Single Coil (Modbus Function Code 05 (0x05))

3.3.3 Write Multiple Coils (Modbus Function Code 15 (0x0F))

3.3.4 Write Multiple Registers (Modbus Function Code 16 (0x10))

Appendix A: Restoring Factory Default Settings

Appendix B: Specifications

Appendix C: Open TCP Legal Notice

Trademark and Copyright Information

This document is Copyright ©2008 by Xytronix Research & Design, Inc. All rights reserved. WebRelay-10™ and ControlByWeb™ are Trademarks of Xytronix Research & Design, Inc. 2008.

Portions of the software used in WebRelay-10™ are open source and appropriate copyright and legal notices are listed at the end of this manual. All other parts of the software are property of Xytronix Research & Design, Inc. ©2008. The hardware design, schematics, PCB layout, concept, graphics, users manual, etc., are property of Xytronix Research & Design, Inc. ©2008. WebRelay-10™ may not be opened, dis-assembled, copied or reverse engineered.

No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying or scanning, for any purpose other than the personal use by the purchaser of this product. Xytronix Research & Design, Inc., assumes no responsibility for any errors that may appear in this document.

Whereas effort has been made to make the information in this document as useful and accurate as possible, Xytronix Research & Design, Inc. assumes no responsibility for the application, usefulness, or completeness of the information contained herein. Under no circumstance will Xytronix Research & Design, Inc. be responsible or liable for any damages or losses including direct, indirect, special, incidental, or consequential damages or losses arising from either the use of any information contained within this manual or the use of any products or services referenced in this manual.

Xytronix Research & Design, Inc. reserves the right to change any product's features, specifications, documentation, warranties, fee schedules, and conditions at any time and without notice.

Warranty

This Xytronix Research & Design, Inc. product has a warranty against defects in material and workmanship for a period of one year from the date of shipment. During the warranty period, Xytronix Research & Design, Inc. will, at its option, either repair or replace products that prove to be defective. This warranty is extended to the original purchaser of the equipment only.

For warranty service or repair, the product must be properly packaged, and returned to Xytronix Research & Design, Inc. The purchaser shall prepay all charges for shipping to Xytronix Research & Design, Inc., and Xytronix Research & Design, Inc. will pay the shipping charges to return the product to the purchaser as long as the product is shipped within the United States. If the product is shipped outside of the United States, the purchaser shall pay all shipping charges, duties, and taxes.

Limitation

The foregoing warranty shall not apply to defects or damage resulting from improper use or misuse, unauthorized repair, tampering, modification, improper connection, or operation outside the electrical/environmental specifications for the product. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes, and tornadoes. This warranty does not cover damage to property, equipment, direct, indirect, consequential, or incidental damage (including damage for loss of business profit, business interruption, loss of data, and the like) arising out of the use or misuse of this product. **UNDER NO CIRCUMSTANCES WILL THE LIABILITY OF XYTRONIX RESEARCH & DESIGN, INC. TO THE PURCHASER OR ANY OTHER PARTY EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT, REGARDLESS OF THE FORM OF THE CLAIM.** No other warranty is expressed or implied. Xytronix Research & Design, Inc. specifically disclaims the implied warranties or merchantability and fitness for a particular purpose. Some jurisdictions may not allow the exclusion of limitation of liability for consequential or incidental damage.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

Warning: This equipment has been tested and found to comply with the limits for a Class B (Class A for POE model) digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Notice: Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Installation Guidelines (Read Before Installing)

- This unit must be installed by qualified personnel.
- This unit must not be installed directly outdoors.
- This unit must not be used for medical, life saving purposes, or for any purpose where its failure could cause serious injury or the loss of life.

Notes about security:

By design, WebRelay-10™ is very secure. It does not support terminal or file transfer programs such as telnet, ftp, ssh, etc. This means that it is not possible for someone to 'break in' to WebRelay-10™ and access other devices on your local network. WebRelay-10™ does not support remote firmware updates which means that it is not possible for someone to remotely install malicious software. The simplicity of WebRelay-10™ makes it a very secure device. As with any device to be installed on a network, there are some security precautions that should be observed. If WebRelay-10™ is installed on the Internet, it is recommended that passwords be enabled for the control page. Make sure secure passwords are used. Passwords should be at least 8 characters in length and should be a combination of upper case letters, lower case letters, and numbers. Don't use passwords that would be easy to guess. For additional security, a firewall may be used to limit access only to selected IP addresses. Another option may be to set up a Virtual Private Network (VPN) between the network where WebRelay-10™ resides and the client machine (web browser, second WebRelay-10™, etc.).

Final installation note. This ControlByWeb™ product supports connection to 10Mbps and 100Mbps networks. Although 100Mbps networks are faster, the amount of data transferred to and from this device is very minimal and little if any performance increase will be gained by setting it to 100Mbps. There are advantages however, to operate this device at 10Mbps. At 10Mbps, less power is required, the unit runs cooler, and the lifetime of the product will be extended.

Section 1: Introduction

WebRelay-10™ is a robust, ten-relay module with a built in web server. It can be controlled and/or monitored over any IP network including private networks, IP-based industrial control networks, and the Internet. Users can operate WebRelay-10™ using a web browser or a custom application. Computers, PLCs, or automation controllers may control and monitor WebRelay-10™ without user intervention. This works by sending text commands over the network and reading XML status pages from WebRelay-10™, or by using Modbus/TCP protocol.

WebRelay-10™ has many applications and is only limited by imagination. It works very well as a stand-alone device that can be controlled using a web browser or as a convenient way to add I/O to a computer. It can be used in industrial applications to control motors, lights, coils, pumps, valves, etc.

1.1 Features

WebRelay-10™ is very simple but has many features. Some features include...

- No programming required
- Easy to use as a stand alone device or as part of a large control system
- Built-in web server provides simple, web based configuration and control
- Control page can be customized with appropriate text and buttons
- 10/100 Ethernet connectivity
- Ten, 240Volt 30-Amp relays
- Custom applications can control WebRelay-10™ with simple text commands and read XML formatted status.
- Modbus/TCP protocol support provides inter-interoperability with devices/software from other manufacturers.
- Password protection
- Selectable TCP ports
- On/Off or pulse mode

1.2 WebRelay-10™ Models Available

WebRelay-10™ is currently available in one model.


Part Number	Power Supply Requirements
X-WR-10R12-I	10-36VDC

1.3 Connectors & Indicators

WebRelay-10™ has ¼ inch male tab connectors for power and relay contacts, an Ethernet connector, and thirteen LED indicators.

Two tab connectors located on the circuit board are used to apply power to the module. Each relay has three tab connectors for direct connection to the relay contacts. All ten relays provide common, normally open, and normally closed contacts. Female mating connectors (not included) are required for connection. The Ethernet connector is located on a small CPU daughter card that is mounted to the main relay board.

Ten green LEDs indicate when each relay is energized. When the relay is energized, the common and normally open contacts are closed which allows current to flow through them (common and normally closed contacts are open). When the relay is not energized, the common and normally closed contacts are closed which allows current to flow through them (common and normally open contacts are open). The LEDs are located close to the corresponding relays. The power LED indicator (green) is located on the small CPU daughter card. The Link LED (green) indicates the Ethernet network is connected and properly linked. The Activity LED (amber) indicates network activity is detected.



Section 2: Installation and Setup

Installation consists of mounting WebRelay-10™, connecting to an IP network, providing power, configuring via a web browser, and wiring relay contacts to the device that will be controlled.

2.1 Mounting

WebRelay-10™ can be mounted to a standard (35mm by 7.55mm) DIN rail. Attach the module to the DIN rail by hooking the top hooks on the back of the PCB card to the DIN rail and then snap the bottom hooks into place. Remove from DIN rail using a flat-head screwdriver.



2.2 Connection

CAUTION: MAKE SURE POWER IS SHUT OFF BEFORE WIRING!

Connection to WebRelay-10™ is made through the ¼ inch male tab connectors. Mating connectors (¼ inch female tab connectors) can be purchased at electrical supply stores.

It is recommended that the load (device to be controlled) not be connected to WebRelay-10™ until after WebRelay-10™ has been configured and tested. By doing this, wiring and configuration mistakes will not cause the load device to turn on unexpectedly.

IMPORTANT: MAKE SURE WIRES ARE PROPERLY ATTACHED (CRIMPED) TO THE CONNECTORS, AND THAT CONNECTORS ARE PROPERLY ATTACHED TO THE CIRCUIT BOARD!

2.2.1 Power Supply Connection

WebRelay-10™ requires power for its internal logic circuits. Connect a 10-36VDC power supply to the Vin+ and Gnd terminals. Note that a regulated power supply is recommended.

Multiple WebRelay-10™ units may be connected to a single power supply by connecting the power supply input terminals in parallel. The power supply must have a high enough current rating to power all units connected (see specifications for current requirements for specific model number).

2.2.2 Network Connection

Connect the Ethernet port to a 10 Base T or 10/100 Base T Ethernet connection. This typically connects to an Ethernet hub, switch, or router. For configuration, WebRelay-10™ may be connected directly to the Ethernet port on a computer using a “crossover” cable. Otherwise for connection through a hub or router, a standard “straight-thru” cable should be used.

2.2.3 Relay Connection

Direct connection to relay contacts is provided through tab connectors located on the top of the relays. Do not exceed specified load ratings for relay contacts (see specifications for load ratings).

2.3 Establishing Communications for Setup

WebRelay-10™ is set up using a web browser. The first task is to establish communications between a computer and the WebRelay-10™ device so that the browser-based configuration can begin. To do this, the computer and WebRelay-10™ must be physically connected to the same network and both must have IP addresses on the same network. There are two ways to set up the computer and WebRelay-10™ so that they are on the same network. The first way (Option 1), is to change the IP address of WebRelay-10™ to an address that is on the same network as the computer. The second way (Option 2) is to change the IP address of the computer to an address that is on the same network that WebRelay-10™ is set to by default.

2.3.1 Option 1: Assign a temporary IP address to WebRelay-10™

This option is used to TEMPORARILY assign an IP address to WebRelay-10™ without the need to change the IP address of the configuration computer. Note that WebRelay-10™ will only use this IP address as long as power is maintained. Once power is lost and restored, WebRelay-10™ will use the IP address assigned in the setup page and not the temporary address assigned here. This means that once communications are established, the desired IP address should be entered into the network setup page using the browser.

To assign the temporary IP address...

1. Make sure WebRelay-10™ and the configuration computer are connected to the same physical network. This will not work through routers or gateways.
2. Assign the address as follows...

Windows:

Open a Command Prompt (on Windows XP, select START, then RUN, then type “cmd”).

Type...

```
arp -s {new IP address} {serial number of WebRelay-10™ }
```

Note: IP address format is: xxx.xxx.xxx.xxx

Serial number format is: ss-ss-ss-ss-ss-ss

For example, to set a WebRelay-10™ device (with serial number 00-0C-C8-01-00-01) to 10.10.10.40 the following command would be used.

```
arp -s 10.10.10.40 00-0c-c8-01-00-01
```

Next, type...

```
ping -l 102 {new IP address}
```

For example, if the new IP address is 10.10.10.40, the following command would be used.

```
ping -l 102 10.10.10.40
```

Linux/Unix:

Open a terminal, change to root user (su -, then enter root password).

Type...

```
arp -s {new IP address} {serial number of WebRelay-10™ }
```

Note: IP address format is: xxx.xxx.xxx.xxx

Serial number format is: ss:ss:ss:ss:ss:ss

For example, to set a WebRelay-10™ device (with serial number 00-0C-C8-01-00-01) to 10.10.10.40 the following command would be used.

```
arp -s 10.10.10.40 00:0c:c8:01:00:01
```

Next, type...

```
ping -s 102 {new IP address}
```

For example, if the new IP address is 10.10.10.40, the following command would be used.

```
ping -s 102 10.10.10.40
```

Mac OS X

Open a terminal,

Note that the terminal is in the “Utilities” directory which is in “Applications” directory.

type

```
sudo arp -s {new IP address} {serial number of WebRelay-10™ }
```

Note: Administrator password is required.

IP address format is: xxx.xxx.xxx.xxx

Serial number format is: ss:ss:ss:ss:ss:ss

For example, to set a WebRelay-10™ device (with serial number 00-0C-C8-01-00-01) to 10.10.10.40 the following command would be used.

```
sudo arp -s 10.10.10.40 00:0c:c8:01:00:01
```

Next, type...

```
ping -s 102 {new IP address}
```

For example, if the new IP address is 10.10.10.40, the following command would be used.


```
ping -s 102 10.10.10.40
```

2.3.2 Option 2: Assign a temporary IP address to configuration computer


If the first option above is not used, you can use this option to communicate with WebRelay-10™ . By default, WebRelay-10™ comes from the factory with an IP address of 192.168.1.2. Communications with WebRelay-10™ may be established by assigning an IP address to the configuration computer that is on the same network as WebRelay-10™ (for example the configuration computer could be assigned to 192.168.1.5) .

Instructions for changing the IP address of the computer that will be used for WebRelay-10™ configuration are given here. Note that these instructions are specifically for computers with the Windows XP operating system. For setup using other operating systems, refer to the appropriate users manual.

Step 1: Open the control panel by clicking on the start menu and then clicking on Control Panel. (Note that control panel shown is in “Classic View”. If control panel is in “Category View” select the “Classic View” option before proceeding.)




Step 2: Double click on the icon labeled Network Connections. The following menu will pop up.




Step 3: Right click on the icon labeled Local Area Connection. Another menu will appear. Select the option at the bottom of the menu labeled Properties. The Local Area Connection Properties window will appear.

Step 4: On the Local Area Connection Properties page scroll down to Internet Protocol (TCP/IP), select it, and then click the button labeled properties.



Step 5: Before making any changes to the network settings, write down the current settings so they can be restored once WebRelay-10™ is configured. Next, select the radio button labeled “Use the following IP address,” and type in the IP address 192.168.1.50. Type in a subnet mask of 255.255.255.0. Leave the default gateway field blank. Click OK to apply settings.



2.3.3 Open Configuration Web Page

Once the network is set up, open the configuration setup page by typing the following URL into the browser: <http://192.168.1.2/setup.html> (note that if option 1 above was used for initial configuration, replace the IP address given here with the newly assigned IP address). A password is required to change any parameters. The default password is 'webrelay' (do not include quotes, password is case sensitive).


2.4 Web-Based Setup

WebRelay-10™ is fully configurable through HTML 4.0 compliant web browsers such as Internet Explorer and Mozilla Firefox. Its easy to use tab based menu system has been designed to allow the unit to be configured easily. Note that in this chapter, the default IP address of 192.168.1.2 is used in all examples. If the IP address has been changed, substitute the new IP address for the address shown in the examples.


Before proceeding, make sure a network connection has been established between the computer and WebRelay-10™. This is done by typing the following URL into the web browser: <http://192.168.1.2/setup.html>. Another way to check communications is to ping WebRelay-10™ (from the command prompt (type ping 192.168.1.2)). Each setup page is described below.

2.4.1 Main Setup Page

This is the initial page that appears when the URL <http://192.168.1.2/setup.html> is entered into the web browser. It provides basic information about the WebRelay-10™ unit.



Navigating between setup pages is done by clicking on the tabs at the top of the page. All setup pages require a password. The default password is ‘webrelay’ (no quotes, all lower case) and no user name is required.




Each setup page has a “Submit” button and a “Reset” button at the bottom of the page. After entering the desired parameters into each page, the “Submit” button must be pressed before any parameters will be saved. If a mistake is made in entering the parameters, the “Reset” button may be used to restore all parameters on the page to their current settings. The “Reset” button is only effective before the “Submit” button is pressed.

2.4.2 Network Setup Page

The network parameters are changed on this page. Note that if multiple WebRelay-10™ units are used on the same network, install one unit at a time and set the IP address of each unit before connecting the next unit to the network. This avoids having multiple WebRelay-10™ units installed on the network with the same factory default IP address at the same time. It may be necessary to clear the arp cache each time you swap WebRelay-10™ units on the network (this is because each unit has the same default IP address but different mac address). This is done by typing `arp -d` in the command prompt of a Windows computer

(`arp -d -a` as super user on Apple OSX). Also note that the unit must be power-cycled (power disconnected, then reconnected) before network settings take effect. No other setup page requires power-cycling for the settings take effect.



1. IP Address:

WebRelay-10™ requires a static IP address. This is a unique address that identifies WebRelay-10™ on the network. Dynamic IP address assignment is not supported. The lack of dynamic IP addressing support is intentional because a dynamically changing the IP address would make it difficult for a client to access the web server built into WebRelay-10™. The IP address is specific to the network where WebRelay-10™ will be installed, and must be obtained from the network administrator.

This guide is not meant to be a tutorial on IP addressing, however a few comments about IP addressing are given here.

If WebRelay-10™ will be used over the Internet, the IP address must be a routable address assigned by the upstream Internet Service Provider (ISP).

In cases where the ISP only provides a single routable IP address for the entire network (this is typical with ISPs such as cable providers), a proxy server (or gateway router) may be used. A proxy server allows multiple devices to connect to the Internet using a single routable IP address. Many small routers from LinkSys, Dlink, and Netgear perform proxy server functions. If a proxy server is used, WebRelay-10™ will not be accessible from the Internet until the proxy server is properly configured (forward proper port to WebRelay-10™). This information is mentioned for

convenience but details of setting up a configuration such as this is beyond the scope of this manual.

If WebRelay-10™ is used on a private network only and is NOT used over the Internet, a routable IP address is not necessary. This may be the case when WebRelay-10™ is used to control (or monitor) a device in another room or a nearby building.

If WebRelay-10™ will be installed on a simple, private network that does not connect to the Internet, the default IP address may be used as long as no other device on the network uses the same address. If multiple WebRelay-10™ units are installed on the same network, each unit must have its own unique IP address. For example, WebRelay-10™ comes from the factory with a default IP address of 192.168.1.2. If multiple units are used, change the IP address for each unit (192.168.1.3, 192.168.1.4, 192.168.1.5 etc.).

2. Netmask:

This specifies the size of the local network. This must be obtained from the network administrator. By default, the netmask is set to 255.255.255.0.

3. Broadcast:

This specifies the broadcast address. This must be obtained from the network administrator. By default, this is set to 192.168.1.255.


4. Gateway:

This specifies the IP address of the gateway router. This must be obtained from the network administrator. By default, this is set to 192.168.1.1.

5. TCP Port:

This specifies the TCP port used for communications with WebRelay-10™. By default, the port is set to 80 which is the standard http port. It is recommended that the port not be changed without an understanding of TCP/IP and ports.

Changing the port can be useful for accessing multiple WebRelay-10™ devices which are installed behind a gateway router on a private network that uses non-routable IP addresses (192.168.x.x, 10.x.x.x, and 172.16.x.x through 172.31.x.x are non-routable or private IP addresses). In this case, each WebRelay-10™ unit would be assigned a different port (for example 8000, 8001, 8002, etc). The gateway router would be set up to forward all traffic for each of the assigned ports to the IP address of the WebRelay-10™ unit which uses that port. The WebRelay-10™ units could then be accessed from outside the private network by entering the IP address of the gateway and the port for the desired WebRelay-10™ unit. Note that whenever any port is assigned other than port 80, all communications with that WebRelay-10™ device must include the port. For example, if WebRelay-10™ is assigned port 8000, access to the setup page would require the following URL to be entered; <http://192.168.1.2:8000/setup.html>.



An example screenshot of a gateway router configuration is given below. This setup allows seven ControlByWeb™ products to be accessed on a private network behind a gateway router. Note that this screenshot is simply an example of a typical router setup page. Routers will vary.

In the example, the seven ControlByWeb™ products are assigned IP addresses of 10.10.10.41 to 10.10.10.47. The first device labeled WebRelay-Quad 1 has an IP address of 10.10.10.41 and is assigned port 8001. Note that in the WebRelay-Quad™ setup page (under Network settings tab), TCP Port 8001 must be specified for this device. The second device, labeled WebRelay-Quad 2 has an IP address of 10.10.10.42 and is assigned port 8002. This WebRelay-Quad™ must have its TCP Port set to 8002 in its network settings page. This pattern continues through 10.10.10.77 which is assigned the port 8007. To access the ControlByWeb™ units from the Internet, enter the IP address of the gateway plus the port number of the desired device.

6. Modbus Port:

This specifies the port used for Modbus/TCP communications with WebRelay-10™. By default this is set to port 502 which is the standard Modbus port. For users not familiar with Modbus, Modbus is a messaging structure protocol used in industrial manufacturing control and automation. It is an open protocol and offers interoperability with software and devices from other manufacturers. If Modbus is not used, this setting can be ignored. Modbus communications are disabled whenever the control password is enabled.

7. Speed:


This option sets the data rate of the Ethernet port. Both 10Mbps and 100Mbps can be selected. The 100Mbps option offers faster communications but the amount of data to and from WebRelay-10™ is so small that users will not likely notice much of a difference. When WebRelay-10™ is set to 10Mbps, it draws less power and runs a little cooler which translate into a longer product life. **IT IS RECOMMENDED THAT THIS SETTING BE LEFT AT 10MBPS UNLESS THE USER HAS A SPECIFIC REASON TO USE 100MBPS.**

8. Mode:

This option allows the Ethernet port to be set to Half Duplex or Full Duplex. Legacy Ethernet operates in Half Duplex mode which means that devices can either send data or receive data, but not both at the same time. Full duplex means that devices can send and receive data at the same time.

2.4.3 Password Setup Page

The password setup page is used to change and enable passwords. A password is required for the setup pages but is optional for the control page. The password is enabled or disabled for the control page by using the *Yes* or *No* radio buttons. Enabling the control page password also enables the requirement for a password when reading/writing XML pages. Enabling the control page password also disables the ability to communicate with WebRelay-10™ using Modbus. Note that when the password is changed, the password may be displayed in the browser's history in clear text. It is advisable to clear the browser's history after setting the password. Passwords may be up to 10 characters.




The screenshot shows a Windows Internet Explorer browser window displaying the WebRelay-10 Setup page. The address bar shows the URL <http://192.168.1.2/setup.html>. The page features the WebRelay-10 logo and a navigation menu with tabs for Network, Password, Control Page Setup, Relay Options, and Control Page. The Password tab is selected, showing a form with the following fields:

- Setup Password: [password field]
- Re-enter Setup Password: [password field]
- Enable Control Password: Yes No
- Control Password: [password field]
- Re-enter Control Password: [password field]

At the bottom of the form are two buttons: Submit and Reset. The browser's status bar at the bottom shows "Done", "Internet", and "100%" zoom level.

2.4.4 Control Page Setup Page

This setup page is used to setup parameters that affect the control page as a whole. It is on this page that the title and main header of the control page is defined, as well as the refresh rate of the control page.



1. Main Header Text:

This text will be displayed in the main header area of the control page. This field can be up to 25 characters in length.

2. Auto Refresh Page:

Web pages traditionally display static information. The WebRelay-10™ control page, however, displays information that is dynamic. Each time the control page is loaded to the browser, it displays a snapshot of the current status of the unit. If the state of the unit changes, the information on the control page will be outdated unless the page is re-loaded. Whenever a user changes the state of the relay via the web browser, the web page will automatically reload the control page to display current information. If, however, the relay state changes due to a change due to a command sent from another machine, the relay state will not be updated and the control page information will be obsolete. The 'Auto Refresh Page' option will cause the control page to continually update its contents by setting a timer in the web page that causes it to be reloaded at a specified time interval.

3. Duration:

If the 'Auto Refresh Page' option is set to **Yes**, this field specifies the time interval in seconds that the page will be refreshed. It can be set from 1 to 32 seconds.

2.4.4 Relay Options Page

This page is used to set up the function of each of the 10 relays, and how each relay is represented on the control page. A drop down box at the top of the page selects the relay for which the options on the page will apply when the setup page is submitted.

http://192.168.1.2/setup.html - Windows Internet Explorer

http://192.168.1.2/setup.html

Google

http://192.168.1.2/setup.html

WEBRelayTM 10

Setup

Network Password Control Page Setup Relay Options Control Page

Select Relay to Edit: Relay 1

Relay 1 Setup:

Relay Description: Relay 1 Description

Status ON Text: Relay ON

Status OFF Text: Relay OFF

Button1 Label: ON

Button2 Label: OFF

Pulse Button Label: Pulse

Pulse Duration: 1.5 secs

Submit Reset

Done Internet 100%

1. Select Relay to Edit:
This drop down box selects the relay for which the rest of the parameters on this setup page will apply. When a new relay is selected the setup page will be refreshed to reflect the current settings for that relay.
2. Relay Description:
This text is used to describe the function of the relay on the control page. This field can be up to 20 characters in length.
3. Status ON Text:
This field specifies the text that will be displayed when the relay is *on* (coil energized).
4. Status OFF Text:

This field specifies the text that will be displayed when the relay is *off* (coil not energized).

5. Button 1 Label:

This field specifies the text that will be displayed in pushbutton number 1.

6. Button 2 Label:

This field specifies the text that will be displayed in pushbutton number 2.

7. Pulse Button Label:

The text entered here will appear in the pulse button on the control page.

8. Pulse Duration:


When WebRelay-10™ receives a command (from over the network or through an input change) to *pulse* the relay, this is the time in seconds that the relay will pulse *on*. This time can be set from 0.1 seconds to 86,400 seconds (1 day). Note that each time WebRelay-10™ receives a pulse command, the relay will be turned *on* (if not *on* already) and the pulse timer will be reset. If WebRelay-10™ receives a pulse command and a second pulse command comes in before the pulse timer has expired, the relay will remain on and the pulse timer will be reset so the duration of the pulse will be extended. If pulse commands are issued continuously so that the pulse timer is not allowed to expire, the relay will remain on until after the last pulse command was sent (to be precise, the relay will go off at the time of the last command plus the Pulse Duration time). The pulse command can be canceled before the pulse duration time has expired by issuing any other command. The factory default setting for this is 1.5 seconds.

Section 3: Operation

WebRelay-10™ can be operated by using a web browser, by sending text commands to an XML status/control page, or by sending Modbus/TCP requests.

3.1 Browser Operation

Once the unit is set up, the control page may be accessed by typing the following URL into the web browser: <http://192.168.1.2> (Note that if the IP address was changed, replace the default IP address shown with the new address that was assigned. Note also that if any port is used other than port 80, the port must also be included in the request: <http://192.168.1.2:8000>) The new control page will appear. A control page with default settings is shown below.



3.2 XML Operation

Custom computer applications may be created to monitor and control WebRelay-10™ without using a web browser. Monitoring the state of the relays is done by sending a GET request to port 80 (or port specified in setup) for the XML page. Control of the relay is done by sending GET requests to the same page. This can be demonstrated by entering commands into the URL line of a web browser.

Request the current state: <http://192.168.1.2/state.xml>

This will return the following XML page.:

```
<?xml version="1.0" encoding="utf-8" ?>
- <datavalues>
  <relay1state>0</relay1state>
  <relay2state>1</relay2state>
  <relay3state>1</relay3state>
  <relay4state>1</relay4state>
  <relay5state>0</relay5state>
  <relay6state>0</relay6state>
  <relay7state>0</relay7state>
  <relay8state>0</relay8state>
  <relay9state>0</relay9state>
  <relay10state>0</relay10state>
</datavalues>
```

The tags `<relay1state>... <relay10state>` indicate the current state of each of the ten relays. Values for the tags are described below.

```
<relayXstate>  0=off(coil off)
                1=on (coil energized)
```

Commands can be sent to WebRelay-10™ to control the relays. Commands are sent using variables called relay1State, relay2State, relay3State, etc, up through relay10State. Examples of using relayXState (X represents the appropriate relay) are given here.

Turn relay 1 'off': <http://192.168.1.2/state.xml?relay1State=0>

Turn relay 1 'on': <http://192.168.1.2/state.xml?relay1State=1>

Turn relay 1 'on' and turn relay3 'off': <http://192.168.1.2/state.xml?relay1State=1&relay3State=0>

Commands can be issued to pulse the relays instead of simply turning them on or off by setting the relayXState to 2.

Pulse relay 10: <http://192.168.1.2/state.xml?relay10State=2>

The example above will cause relay 10 to pulse. The pulse time is specified in the setup page for each relay.

Commands can also specify pulse times so that the relay can be pulsed for times other than the times specified in the relay setup pages. This is done by sending an additional variable called pulseTimeX (once again, X represents the appropriate relay).

Pulse relay10: <http://192.168.1.2/state.xml?relay10State=2&pulseTime10=5.5>

The example above will cause relay 10 to pulse for 5.5 seconds.

Note that the pulseTimeX variable does not change the pulse time specified in the setup page and it is not stored or recorded. The pulseTimeX variable only changes the pulse duration for the single pulse initiated by that command. In other words, you must issue the pulseTimeX for each pulse command that differs from the preset pulse time. For example, suppose the pulse time is set to 1.5 seconds in the configuration pages. To issue one 1.5 second pulse, three five second pulses, and a 1.5 second pulse once again, you would issue the following commands...

[state.xml?relay1State=2](http://192.168.1.2/state.xml?relay1State=2)

This will pulse the relay for the preset time (1.5 seconds)

[state.xml?relay1State=2&pulseTime1=5](http://192.168.1.2/state.xml?relay1State=2&pulseTime1=5)

This will pulse the relay for 5 seconds.

state.xml?relay1State=2&pulseTime1=5 This will pulse the relay for 5 seconds
state.xml?relay1State=2&pulseTime1=5 This will pulse the relay for 5 seconds
state.xml?relay1State=2 This will pulse the relay for the preset time (1.5 seconds)
(Note that <http://192.168.1.2/> would be included on all commands above)

Multiple relays can be changed with a single command by submitting multiple relayXState variables separated by an ampersand symbol (&). All four relayXState variables or a subset of the relayXState variables can be included. The relayXState variables can be in any order. Relays that are already in the desired state will not be affected by on/off commands. Note that pulse commands will reset the pulse timer each time a command is received.

The following line illustrates how to turn 'on' relay 1, turn 'on' relay 2, and turn 'off' relay 10.
<http://192.168.1.2/state.xml?relay1State=1&relay10State=0&relay2State=1>

When the above commands are sent to WebRelay-10™, its current state is returned in the form of an XML page. The commands can also be sent without having WebRelay-10™ return the XML page. This is accomplished by adding the noReply field as follows.

Turn relay3 'on' without returning state: <http://192.168.1.2/state.xml?relay3State=1&noReply=1>
Turn relay3 'off' without returning state: <http://192.168.1.2/state.xml?relay3State=0&noReply=1>

Password :

If the control password is enabled in the WebRelay-10™ unit and the XML page is requested through a browser, the browser will prompt the user for the password. If the XML request is sent from another application and not a browser, the html request will need to contain the password encoded using the base 64 encoding scheme. The html request header without the password looks like this:

```
GET /state.xml?noReply=1 HTTP/1.1 (Ends with two \r\n)
```

The html request header with the password looks like this:

```
GET /state.xml?relay2State=1&noReply=1 HTTP/1.1 (Ends with two \r\n)
Authorization: Basic bm9uZTp3ZWJyZWxheQ== (Ends with two \r\n)
```

where bm9uZTp3ZWJyZWxheQ== is the base 64 encoded version of the username and password
none:webrelay

A utility is provided at <http://www.ControlByWeb.com/encoder> that can be used to encode the password. The utility is used by simply typing the string username:password into the website and pressing encode.

3.3 Modbus Operation

WebRelay-10™ can be controlled (and read) using Modbus/TCP protocol. This provides a standard means of using WebRelay-10™ in conjunction with devices and software from other manufacturers. This section contains the information necessary to communicate with WebRelay-10™ using Modbus/TCP. This is not a tutorial on Modbus and it is assumed that reader is already familiar with Modbus. Detailed Modbus information can be found at <http://www.modbus.org>.

It is important to note that when the control password in WebRelay-10™ is enabled, Modbus/TCP communications are disabled. This is because Modbus/TCP does not provide a mechanism for password protection. Make sure the control password is disabled (default) before using Modbus with WebRelay-10™.

WebRelay-10™ functions as a Modbus server. Client devices open a connection with WebRelay-10™ on port 502 (unless another modbus port is selected) and sends commands or requests to read the state of a relay, or change a relay. When WebRelay-10™ receives a command, it will perform the desired function and return a response. The

following commands are available:

Read Coils (Modbus function 01) - read the status of the relay (and/or the input).

Write Single Coil (Modbus function 05) - change the relay state

Write Multiple Coils (Modbus Function Code 15) – change multiple relays at the same time

Write Multiple Registers (Modbus function 16) - pulse the relay or multiple relays.

Multiple commands may be sent without closing and re-opening the connection but if no data is transferred for about 50 seconds the connection will time out. To keep the connection open, a read request can be sent periodically.

3.3.1 Read Coils (Modbus Function Code 01 (0x01))

This function returns the state of the relay coil(s).

Relay 1 is at address 0x0000, relay 2 is at address 0x0001, relay 3 is at address 0x0002, and and so on. Multiple relays may be read at the same time by specifying the correct starting address and quantity of coils.

Request

Modbus/TCP:

Transaction identifier (2 Bytes): 0x0001

Protocol identifier (2 Bytes): 0x0000

Length (2 Bytes): 0x0006

Unit identifier (1 Byte): 0xff

Modbus:

Function code (1 Byte): 0x01 (read coils)

Starting address (2 Bytes): 0x0000 (0x0000 ~ 0x0009)

Quantity of coils (2 Bytes): 0x0002 (0x0001 ~ 0x000A)

Character String Example:

```
char read_coils_mb_request[] = {0x00, 0x01, 0x00, 0x00, 0x00, 0x06, 0xff, 0x01, 0x00, 0x00,
0x00, 0x02 };
```

Response

Modbus/TCP:

Transaction identifier (2 Bytes): 0x0001

Protocol identifier (2 Bytes): 0x0000

Length (2 Bytes): 0x0004 – 0x0005 (Depending on how many coils are read)

Unit identifier (1 Byte): 0xff

Modbus:

Function code (1 Byte): 0x01 (Read coils)

Byte count (1 Byte): 0x01

Coil status (1-2 Bytes): 0x00 to 0x3FF (Depending on how many coils are read)

Modbus Error:

Function code (1 Byte): 0x81

Exception code (1 Byte): 0x01 or 0x02

Exception codes:

0x01 - Function code not supported

0x02 - Incorrect starting address / quantity of outputs combination

Character String Example:


```
char read_coils_mb_response[] = {0x00, 0x01, 0x00, 0x00, 0x00, 0x04, 0xff, 0x01, 0x01, 0x01};
```

3.3.2 Write Single Coil (Modbus Function Code 05 (0x05))

Request

Modbus/TCP:

Transaction identifier (2 Bytes): 0x0001
 Protocol identifier (2 Bytes): 0x0000
 Length (2 Bytes): 0x0006
 Unit identifier (1 Byte): 0xff

Modbus:

Function code (1 Byte): 0x05 (write coil)
 Output address (2 Bytes): 0x0000 – 0x0009 (specifies relay)
 Output value (1 Byte): 0xff - turn relay on, 0x00 - turn relay off
 Padding (1 Byte): 0x00

```
char write_coil_mb_request[] = {0x00, 0x01, 0x00, 0x00, 0x00, 0x06, 0xff, 0x05, 0x00, 0x00, 0xff, 0x00};
```

Response

Modbus/TCP:

Transaction identifier (2 Bytes): 0x0001
 Protocol identifier (2 Bytes): 0x0000
 Length(2 Bytes): 0x0006
 Unit identifier (1 Byte): 0xff

Modbus:

Function code (1 Byte): 0x05 (write coil)
 Reference number (2 Bytes): 0x0000
 Data (1 Byte): 0xff - relay on, 0x00 - relay off
 Padding (1 Byte): 0x00

Modbus Error:

Function code (1 Byte): 0x85
 Exception code (1 Byte): 0x01 or 0x02

Exception codes:

0x01 - Function code not supported
 0x02 - Incorrect starting address / quantity of outputs combination

```
char write_coil_mb_response[] = {0x00, 0x05, 0x00, 0x00, 0x00, 0x06, 0xff, 0x05, 0x00, 0x00, 0xff, 0x00};
```

3.3.3 Write Multiple Coils (Modbus Function Code 15 (0x0F))

One to two bytes can be written to set the state of all 10 relays. Each bit represents one relay with the least significant bit of the first byte representing relay 1 and the 2nd bit of byte two representing relay 10.

Request

Modbus/TCP:

Transaction identifier (2 Bytes): 0x0001
 Protocol identifier (2 Bytes): 0x0000
 Length (2 Bytes): 0x0008 – 0x0009 (Depending on how many relays)
 Unit identifier (1 Byte): 0xff

Modbus:

Function code (1 Byte): 0x0f (write coil)
 Starting address (2 Bytes): 0x0000 ~ 0x0009
 Quantity of outputs (2 Bytes): 0x0001 ~ 0x000A
 Byte count (1 Byte): 0x01
 Output value (1 to 2 Bytes): 0x0000 ~ 0x3fff

```
char write_mult_coil_mb_request[] = {0x00, 0x01, 0x00, 0x00, 0x00, 0x08, 0xff, 0x0f, 0x00, 0x00,
0x00, 0x01, 0x01, 0x0f};
```

Response**Modbus/TCP:**

Transaction identifier (2 Bytes): 0x0001
 Protocol identifier (2 Bytes): 0x0000
 Length(2 Bytes): 0x0006
 Unit identifier (1 Byte): 0xff

Modbus:

Function code (1 Byte): 0x05 (write coil)
 Starting address (2 Bytes): 0x0000
 Quantity of outputs (1 Byte)

Modbus Error:

Function code (1 Byte): 0x8f
 Exception code (1 Byte): 0x01 or 0x02

Exception codes:

0x01 - Function code not supported
 0x02 - Incorrect starting address / quantity of outputs combination

```
char write_coil_mb_response[] = { 0x00, 0x05, 0x00, 0x00, 0x00, 0x06, 0xff, 0x05, 0x00, 0x00,
0xff, 0x00};
```

3.3.4 Write Multiple Registers (Modbus Function Code 16 (0x10))

This is used to pulse the relay(s) for a specified time. When WebRelay-10™ receives this command, it immediately turns the appropriate relay coil(s) on (if not on already on) and starts the pulse timer. The relay(s) are selected by writing the pulse time to the register(s) associated with the appropriate relay(s). The pulse time is specified in the register value field and can range from 0.1 seconds to 86400 seconds (1 day). When the pulse time expires, the relay coil will be turned off. If a pulse time command is sent with a value greater than 86400, the pulse timer will be set to 86400. If a pulse time command is sent with a value less than 0.1, the pulse timer will be set to 0.1. If any commands are sent to WebRelay-10™ (commands may be modbus, xml or html) before the pulse timer has expired, the pulse timer will be canceled immediately and the new command will be executed.

The pulse time is provided in IEEE 754 floating point format. The four data bytes are treated as two individual big endian 16-bit words but the least significant word is sent first. In other words, the 32-byte floating point number represented as ABCD is sent as CDAB. In the example shown below, the relay will pulse for 10 seconds. Ten seconds is represented using a floating point number of 41200000. It is transferred as 00004120.

Request**Modbus/TCP:**

Transaction identifier (2 bytes): 0x0001
 Protocol identifier (2 bytes): 0x0000

Length (2 bytes): 0x000b
 Unit identifier (1 byte): 0xff

Modbus:

Function code (1 Byte): 0x10 (Write Multiple Registers)
 Starting address (2 Bytes): 0x0010 (0x0010 relay 1, 0x0012 relay 2, 0x0014 relay 3, 0x0016 relay 4,, 0x0023 relay 10)
 Number of registers (2 Bytes): 0x0002-0x0014 (2 registers for each relay to be pulsed)
 Byte count (1 Byte): 0x04 - 0x28 (2 times the number of registers)
 Register values (4 Bytes for each relay to be pulsed): 00 00 41 20 (10 second pulse time)

```
char write_registers_mb_request = {0x00, 0x01, 0x00, 0x00, 0x00, 0x0b, 0xff, 0x10, 0x00, 0x10,
0x00, 0x02, 0x04, 0x00, 0x00, 0x41, 0x20 };
```

Response

Modbus/TCP:

Transaction identifier (2 Bytes): 0x0001
 Protocol identifier (2 Bytes): 0x0000
 Length (2 Bytes): 0x0006
 Unit identifier: 0xff

Modbus:

Function (1 Byte): 0x10 (Write Multiple Registers)
 Reference number (2 Bytes): 0x0010
 Word count (2 Bytes): 0x0002

Modbus Error:

Function code (1 Byte): 0x90
 Exception code (1 Byte): 0x01, 0x02, 0x03, or 0x04

Exception codes:

0x01 - Function code not supported
 0x02 - Incorrect starting address / quantity of outputs combination

```
char write_registers_mb_response[] = {0x00, 0x05, 0x00, 0x00, 0x00, 0x06, 0xff, 0x10, 0x00,
0x10, 0x00, 0x02 };
```

Appendix A: Restoring Factory Default Settings

In the event that the IP address or passwords are forgotten, WebRelay-10™ may be restored to its original factory default settings. To do this, first remove the power from the unit. Next, press the small button that is located on the front of the CPU daughter-board. When the button is pressed, a tactile feel can be detected. While holding the button down, apply power and wait for about 5 seconds. After 5 seconds, release the button. All settings will be restored to factory default settings.

Appendix B: Specifications

Power Requirements:

Model X-WR-10R12-I

Voltage: 10-36VDC

Current: See table below for typical values

10Mbps Network Speed:

Power Supply	No Relays Energized	1 Relay Energized	5 Relays Energized	10 Relays Energized
10 VDC	.125A	.244A	.740A	1.464A
12 VDC	.103A	.198A	.573A	1.111A
24 VDC	.063A	.110A	.293A	.529A
36 VDC	.043A	.079A	.204A	.357A

100Mbps Network Speed:

Power Supply	No Relays Energized	1 Relay Energized	5 Relays Energized	10 Relays Energized
10 VDC	.214A	.323A	.808A	1.550A
12 VDC	.178A	.267A	.655A	1.195A
24 VDC	.096A	.144A	.321A	.561A
36 VDC	.072A	.109A	.231A	.386A

I/O: 10 Relays

Relay Contacts:

Contact Arrangement: Form C (SPDT)

Contact Rating:

- N.O.- 40A @ 240VAC resistive
30A @ 277VAC General Purpose
2hp @ 250VAC
- N.C.- 30A @ 240 VAC resistive
30VDC
20A @ 277VAC General Purpose
1-1/2 hp @ 250VAC

Contact Resistance: < 30 milliohms initial

Contact Material: AgSnO2

Max Switching Power: 9600VA, 1120W

Max Switching Voltage: 277VAC, 110VDC

Max Switching Current: 40A

Electrical Life @ Rated Load: 100K cycles, typ

Mechanical Life: 10M cycles, typ

Connectors: ¼ inch Tab Connectors

Network: 10/100Base-T Ethernet

Network Setup: static IP address assignment, TCP port selectable

Relay Control Options: ON/OFF or Pulsed

Pulse Timer Duration: 100ms to 86400 Seconds (1 day)

LED Indicators: 13

- Module Powered
- Relay Coils Energized 1-10
- Network linked
- Network activity

Physical:

Operating Temperature: -40° to 158°F (-40° to 70°C)

Size: 9.125in (232mm) wide

4.25in (126mm) deep

2.425in (62mm) tall

Weight: 22oz (626 grams)

Monitor Control: Web Browser, XML, or Modbus/TCP

Password Settings:

Password protection on setup page: Yes

Password protection on control page: Optional

Password Encoding: Base 64

Max password length: 10 characters

Regulatory Compliance:

Electromagnetic Compliance:

IEC CISPR 22, CISPR 24

FCC 47CFR15 (-I and -5 Models class B, POE Model Class A)

EU EN55024, EN55022

Product Safety:

IEC 60950-1 / EN 60950-1



Appendix C: Open TCP Legal Notice

Portions of the software used in WebRelay-10™ are open source. The appropriate notices are listed below. All other parts of the software are property of Xytronix Research & Design, Inc. ©2005-2006.

Copyright (c) 2000-2002 Viola Systems Ltd.
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The end-user documentation included with the redistribution, if any, must include the following acknowledgment:
"This product includes software developed by Viola Systems (<http://www.violasystems.com/>)."

Alternately, this acknowledgment may appear in the software itself, if and wherever such third-party acknowledgments normally appear.

4. The names "OpenTCP" and "Viola Systems" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact opentcp@opentcp.org.
5. Products derived from this software may not be called "OpenTCP", nor may "OpenTCP" appear in their name, without prior written permission of the Viola Systems Ltd.

THIS SOFTWARE IS PROVIDED "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL VIOLA SYSTEMS LTD. OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

OpenTCP is the unified open source TCP/IP stack available on a series of 8/16-bit microcontrollers, please see <<http://www.opentcp.org>>.

For more information on how to network-enable your devices, or how to obtain commercial technical support for OpenTCP, please see <<http://www.violasystems.com/>>.