

**WAN Ethernet Port**

## Logging/NTP

## USB Printer

Settings in this section determine whether your base station is easily visible to the public via the WAN Ethernet port. For increased security, uncheck all the options.

 **Enable SNMP Access** **Enable Remote Configuration** **Enable Default Host at** 0.0.0. [ ] **Enable Remote Printer Access** **Enable NAT Port Mapping Protocol**

(available only to computers running Mac OS X 10.4 or later)

Contact: Information Technology Center

Location: Student Union

Change password...

Base Station Options...

AirPort Network

Name: Student Center Upstairs

Cancel

OK