



Restart



Upload



Default



Password



Profiles

AirPort

Internet

Network

Port Mapping

Access Control

WDS

 Enable this base station as a WDS main base station Allow wireless clients on this base

remote base station

relay base station

Click (+) to scan for base stations and wireless networks in range of your computer which you can use as WDS remote base stations. Click (-) to remove a WDS remote base station.

Type	Name	AirPort MAC Address

+

-

- A main base station is connected to the Internet and shares its connection with remote and relay base stations.
- A remote base station shares the main base station's Internet connection.
- A relay base station is connected to the main base station and shares its Internet connection with remote and other relay base stations.



Revert

Update